

357/.1	Bearing housing	2			
360	Valve plate	2	•	•	
360.1	Valve spacer	6			
364	Mechanical seal cover	2			
400	Flange gasket	4		•	
404	O-Ring	2		•	
407/.1	Liquid gasket	1		•	
407.1	Cover-plate gasket	2			
407	Plate-casing gasket	2			
435	Valve	2		•	
436	Mechanical seal, drive end	1	•	•	
437	Mechanical seal, non-drive end	1	•	•	
507	V-Seal	2	•	•	
507.1	V-Seal	1	•	•	
562	Locating pin	2	$\rightarrow$	$\diamond$	
563	Screw	24	$\rightarrow$	$\diamond$	
563	Screw	8	$\rightarrow$	$\diamond$	
563.4	Nut	24	$\rightarrow$	$\diamond$	
603	Bearing cover, drive end	1			
604	Bearing cover, non-drive end	1			
804	Screw	8			
807	Screw	8			
844	Impeller nut	1			
844.2	Screw	2	$\diamond$	$\diamond$	
845	Bearing nut	1	•	•	
845.1	Washer	1	•	•	
863	Screw	8	$\rightarrow$	$\Leftrightarrow$	
902	Screw	6	$\diamond$	$\diamond$	
	Rod	8			
915.2	Plug	8	$\Leftrightarrow$	$\diamond$	
921	Nut	16	$\diamond$	$\diamond$	
945	Coupling key	1	$\diamond$	$\diamond$	
946	Impeller key	1	$\Leftrightarrow$	$\diamond$	
	Repair Kit	1			
∻	Kit of nuts and bolts	1			
Minimum Order: Domestic \$100.00; Foreign \$300.00 All Prepaid & Add orders are subject to applicable handling charge					

dd orders are subject to applicable handling charge

Credit Card Orders are Subject to 1.5% Discount

EX-WORKS BATAVIA, NY USA DOMESTIC PACKING

## 10 % Additional Charge for Export Packing

PRICES ARE SUBJECT TO CHANGE WITHOUT NOTICE

Subject to Graham Standard Conditions of Sale Graham Corporation, Corporate and Sales Headquarters: 20 Florence Avenue, Batavia NY USA 14020

Phone: 585-343-2216 . Fax: 585-343-1097 . E-mail: equipment@graham-mfg.com . Web site: www.graham-mfg.com